

- Combination Weekly Setting:
- While in the "Program setting" mode above, various combinations of week days may be programmed into the timer as below:
(Mo, Tu, We, Th, Fr, Sa, Su) (Mo) (Tu) (We) (Th) (Fr) (Sa) (Su) (Mo, Tu, We, Th, Fr) (Sa, Su) (Mo, Tu, We, Th, Fr, Sa) (Mo, We, Fr) (Tu, Th, Sa) (Mo, Tu, We) (Th, Fr, Sa) (Mo, We, Fr, Su) -----
(Mo, Tu, We, Th, Fr, Sa, Su)

★ **Timer ON/OFF turn on or turn off mode**

- Press "ON/AUTO/OFF", there is an indicator in the display show "ON" or "ON AUTO" or "OFF" or "AUTO OFF".
- Press the indicator to "ON", the time will give a permanent "switch on" "output".
- Press the indicator to "ON AUTO" or "AUTO OFF", the timer will be switched on and switched off during the setted time.
- Press the indicator to "OFF", the timer is turned off.

★ **Special Functions:**

- Press "WEEK" and "HOUR" simultaneously. The display will show "RND" at the right hand side and indicates that the timer is in "RANDOM". Auto mode will delay on/off timing from the actual settings from 2 to 32 minutes.
- Press "HOUR" and "MIN" simultaneously. The display will show " (H) " at the right hand side and the correct time of day will move of forward 1 hour to adjust for Daylight Savings Time.
- Press "HOUR" and "MIN" again to revert correct time of day back to standard time.
- The accuracy of the timer is 2 minutes per month.

★ **When the following situations occurs:**

- When timer does not power on or off according to the settings, check whether the settings are correct, or reset;
- If it is the right time to turn on or off but the timer starts to work in advance, or delay in shutting down, there may be multiple sets of switch programs, please check whether the settings are correct, or reset.
- If above-mentioned two points are right, but the timer still works incorrectly, please check and adjust the mode.
- If the timer does not display or display blurred, please charge the timer.
- If it still fails when the above situations are ruled out, please contact with us or dealer to solve.

★ **Note:**

- The sum of electrical power shall not exceed the rated power;
- This product is electronic product, shall not be used as children's toys;
- Please use this product in dry conditions indoors;
- Do not dismantle timer. Professionals are needed for maintenance.

Timer Instruction Manual

Please read the instructions carefully before using.

● **Features:**

- ★ Patent design
- ★ Longer service life with optimal designed copper structure.
- ★ Min. setting time is 1 sec/min. It can set 8/20 programs of on and off every day.
- ★ Function mode to switch to a normal on state or to timing condition.

Button instructions

- "CLOCK": function-key, exit the current setting.
- "SETUP (PROG)": set 8/20 groups of on and off.
- "MODE (M)": control mode switching.
- "SEC": set the seconds.
- "HOUR": set the hours.
- "WEEK": set the weeks.
- "MINUTE": set the minutes.
- "RESET": reset the groups of on and off.

Usage:

★ **Time Setting**

The correct time of day and day of week must be set prior to using the timer for the first time.

- Press "CLOCK" and "WEEK" to set the day of the week. Press "WEEK" for more than 2 seconds, it can be adjusted rapidly.
- Press "CLOCK" and "HOUR" to set the hour of the day. Press "HOUR" for more than 2 seconds, it can be adjusted rapidly.
- Press "CLOCK" and "MIN" to set minutes. Press "MIN" for more than 2 seconds, it can be adjusted rapidly.
- Press "CLOCK" and "SEC" to set the day of the second. Press "SEC" for more than 2 seconds, it can be adjusted rapidly.

★ **Program Setting:**

There are 8/20 possible program combinations available.

- Press "SETUP (PROG)" to enter program mode. The display will show a "1ON" in the left side of display.
- Press "HOUR", "MIN", and "WEEK" to program the correct day and time when you desire the timer should turn on.
- Press "SETUP (PROG)" to set the timer for "OFF" time and day for "1OFF".
- Press "HOUR", "MIN", and "WEEK" to program the correct day and time.
- If needed, press "SETUP (PROG)" to advance the second on/off setting.